

Alcolizer Easy Check

Personal Alcohol Breath Tester



The portable *Easy Check* breathalyser is specifically designed for personal use and priced accordingly. An easy to use one button operation gives the user accurate and reliable results.

By pressing the button, the LCD screen shows "BLO" when it is ready to take a test. Blowing into the mouthpiece until the tone sounds, indicates the test is completed and the result will show on the screen.

The Easy Check utilises the same electro chemical fuel cell technology widely used by law enforcement and industry in Australia & New Zealand. Its specifications are equivalent to more sophisticated devices, therefore providing the user with a high quality, reliable breath alcohol analyser at a reasonable price.

The LCD shows the breath alcohol content to the nearest 1µg/l. When not in use, the unit powers down into a battery saving mode, but does not turn off completely, so it is ready to use without delay.

Powered by 2 AAA alkaline batteries the EC can be used anywhere. Extra mouthpieces are available from your distributor. Recalibration service usually takes 2-7 days, and this clever little unit tells you when its due.



Alcolizer Easy Check

Specifications

Size	14.5cm x 6.8cm x 2.5cm
Weight	200 grams
Accuracy	Better than +/- 40ug/l from 0ug/l to 450ug/l (2.31) scale BrAC.
Number of tests	200 tests or six months between calibrations
Batteries	2 x AAA alkaline
Operation in ambient temperature	5°C to +40°C (30°F to 100°F)
Purge cycle	30 seconds
Breath sample requirement	5 second moderate and continuous breath sample
Readout	Immediate after analysis
Smoking caution	Wait 3 minutes
Drinking (alcohol consumption) caution	Wait 15 minutes
Mouthpieces	Round disposable
Calibration	ESR breath alcohol testing laboratory
Display	LCD with backlight
BAC format	NZ Breath alcohol units
Complete Package Inclusions	Easy Check unit Plastic storage case 4 mouthpieces Operators Manual Warranty Card Recalibration Form
Optional Equipment	Extra mouthpieces available from your distributor in 5 or 100 piece bags

Distributed in New Zealand by:
 Diagnostic Bioserve Limited
www.dbl.co.nz

Your Distributor: